

Nokia Customer Care

Service Manual

RM-470 (Nokia 6700 classic; L3&4)

Mobile Terminal

Part No: (Issue 1)

COMPANY CONFIDENTIAL



Amendment Record Sheet

Amendment No	Date	Inserted By	Comments
Issue 1	04/2009	NS	

Copyright

Copyright © 2008 Nokia. All rights reserved.

Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

Nokia, Nokia Connecting People, and Nokia X and Y are trademarks or registered trademarks of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Nokia operates a policy of continuous development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.

Under no circumstances shall Nokia be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. Nokia reserves the right to revise this document or withdraw it at any time without prior notice.

The availability of particular products may vary by region.

IMPORTANT

This document is intended for use by qualified service personnel only.

Warnings and cautions

Warnings

- IF THE DEVICE CAN BE INSTALLED IN A VEHICLE, CARE MUST BE TAKEN ON INSTALLATION IN VEHICLES FITTED WITH ELECTRONIC ENGINE MANAGEMENT SYSTEMS AND ANTI-SKID BRAKING SYSTEMS. UNDER CERTAIN FAULT CONDITIONS, EMITTED RF ENERGY CAN AFFECT THEIR OPERATION. IF NECESSARY, CONSULT THE VEHICLE DEALER/MANUFACTURER TO DETERMINE THE IMMUNITY OF VEHICLE ELECTRONIC SYSTEMS TO RF ENERGY.
- THE PRODUCT MUST NOT BE OPERATED IN AREAS LIKELY TO CONTAIN POTENTIALLY EXPLOSIVE ATMOSPHERES, FOR EXAMPLE, PETROL STATIONS (SERVICE STATIONS), BLASTING AREAS ETC.
- OPERATION OF ANY RADIO TRANSMITTING EQUIPMENT, INCLUDING CELLULAR TELEPHONES, MAY INTERFERE WITH THE FUNCTIONALITY OF INADEQUATELY PROTECTED MEDICAL DEVICES. CONSULT A PHYSICIAN OR THE MANUFACTURER OF THE MEDICAL DEVICE IF YOU HAVE ANY QUESTIONS. OTHER ELECTRONIC EQUIPMENT MAY ALSO BE SUBJECT TO INTERFERENCE.
- BEFORE MAKING ANY TEST CONNECTIONS, MAKE SURE YOU HAVE SWITCHED OFF ALL EQUIPMENT.

Cautions

- Servicing and alignment must be undertaken by qualified personnel only.
- Ensure all work is carried out at an anti-static workstation and that an anti-static wrist strap is worn.
- Ensure solder, wire, or foreign matter does not enter the telephone as damage may result.
- Use only approved components as specified in the parts list.
- Ensure all components, modules, screws and insulators are correctly re-fitted after servicing and alignment.
- Ensure all cables and wires are repositioned correctly.
- Never test a mobile phone WCDMA transmitter with full Tx power, if there is no possibility to perform the measurements in a good performance RF-shielded room. Even low power WCDMA transmitters may disturb nearby WCDMA networks and cause problems to 3G cellular phone communication in a wide area.
- During testing never activate the GSM or WCDMA transmitter without a proper antenna load, otherwise GSM or WCDMA PA may be damaged.

For your safety

QUALIFIED SERVICE

Only qualified personnel may install or repair phone equipment.

ACCESSORIES AND BATTERIES

Use only approved accessories and batteries. Do not connect incompatible products.

CONNECTING TO OTHER DEVICES

When connecting to any other device, read its user's guide for detailed safety instructions. Do not connect incompatible products.

Care and maintenance

This product is of superior design and craftsmanship and should be treated with care. The suggestions below will help you to fulfil any warranty obligations and to enjoy this product for many years.

- Keep the phone and all its parts and accessories out of the reach of small children.
- Keep the phone dry. Precipitation, humidity and all types of liquids or moisture can contain minerals that will corrode electronic circuits.
- Do not use or store the phone in dusty, dirty areas. Its moving parts can be damaged.
- Do not store the phone in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the phone in cold areas. When it warms up (to its normal temperature), moisture can form inside, which may damage electronic circuit boards.
- Do not drop, knock or shake the phone. Rough handling can break internal circuit boards.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the phone.
- Do not paint the phone. Paint can clog the moving parts and prevent proper operation.
- Use only the supplied or an approved replacement antenna. Unauthorised antennas, modifications or attachments could damage the phone and may violate regulations governing radio devices.

All of the above suggestions apply equally to the product, battery, charger or any accessory.

ESD protection

Nokia requires that service points have sufficient ESD protection (against static electricity) when servicing the phone.

Any product of which the covers are removed must be handled with ESD protection. The SIM card can be replaced without ESD protection if the product is otherwise ready for use.

To replace the covers ESD protection must be applied.

All electronic parts of the product are susceptible to ESD. Resistors, too, can be damaged by static electricity discharge.

All ESD sensitive parts must be packed in metallized protective bags during shipping and handling outside any ESD Protected Area (EPA).

Every repair action involving opening the product or handling the product components must be done under ESD protection.

ESD protected spare part packages **MUST NOT** be opened/closed out of an ESD Protected Area.

For more information and local requirements about ESD protection and ESD Protected Area, contact your local Nokia After Market Services representative.

Battery information

Note: A new battery's full performance is achieved only after two or three complete charge and discharge cycles!

The battery can be charged and discharged hundreds of times but it will eventually wear out. When the operating time (talk-time and standby time) is noticeably shorter than normal, it is time to buy a new battery.

Use only batteries approved by the phone manufacturer and recharge the battery only with the chargers approved by the manufacturer. Unplug the charger when not in use. Do not leave the battery connected to a charger for longer than a week, since overcharging may shorten its lifetime. If left unused a fully charged battery will discharge itself over time.

Temperature extremes can affect the ability of your battery to charge.

For good operation times with Li-Ion batteries, discharge the battery from time to time by leaving the product switched on until it turns itself off (or by using the battery discharge facility of any approved accessory available for the product). Do not attempt to discharge the battery by any other means.

Use the battery only for its intended purpose.

Never use any charger or battery which is damaged.

Do not short-circuit the battery. Accidental short-circuiting can occur when a metallic object (coin, clip or pen) causes direct connection of the + and - terminals of the battery (metal strips on the battery) for example when you carry a spare battery in your pocket or purse. Short-circuiting the terminals may damage the battery or the connecting object.

Leaving the battery in hot or cold places, such as in a closed car in summer or winter conditions, will reduce the capacity and lifetime of the battery. Always try to keep the battery between 15°C and 25°C (59°F and 77°F). A phone with a hot or cold battery may temporarily not work, even when the battery is fully charged. Batteries' performance is particularly limited in temperatures well below freezing.

Do not dispose of batteries in a fire!

Dispose of batteries according to local regulations (e.g. recycling). Do not dispose as household waste.

Company policy

Our policy is of continuous development; details of all technical modifications will be included with service bulletins.

While every endeavour has been made to ensure the accuracy of this document, some errors may exist. If any errors are found by the reader, NOKIA MOBILE PHONES Business Group should be notified in writing/e-mail.

Please state:

- Title of the Document + Issue Number/Date of publication
- Latest Amendment Number (if applicable)
- Page(s) and/or Figure(s) in error

Please send to:

NOKIA CORPORATION

Nokia Mobile Phones Business Group

Nokia Customer Care

PO Box 86

FIN-24101 SALO

Finland

E-mail: Service.Manuals@nokia.com

(This page left intentionally blank.)

Nokia 6700 classic; L3&4 Service Manual Structure

- 1 General information
- 2 Service Devices and Service Concepts
- 3 BB Troubleshooting and Manual Tuning Guide
- 4 RF troubleshooting
- 5 System Module
- Glossary

(This page left intentionally blank.)

Nokia Customer Care

1 — General information

(This page left intentionally blank.)

Table of Contents

Product selection	1-5
Phone features	1-5
Software and user interface features	1-6
Accessories	1-6
Technical specifications	1-7
General specifications	1-7
Main RF characteristics for GSM850/900/1800/1900 and WCDMA band I, II and VIII phones	1-7
Battery endurance	1-8
Environmental conditions	1-9

List of Tables

Table 1 Battery and chargers	1-6
Table 2 Car accessories	1-7
Table 3 Headsets	1-7
Table 4 Cables	1-7

List of Figures

Figure 1 RM-470 (Nokia 6700 classic) product picture	1-5
--	-----

(This page left intentionally blank.)

■ Product selection

RM-470 (Nokia 6700 classic) is a GSM/WCDMA dual mode phone, supporting EGSM850/900/1800/1900 and WCDMA bands I, II and VIII.



Figure 1 RM-470 (Nokia 6700 classic) product picture

■ Phone features

Display and keypad features

- 2.2" QVGA display with 16M colors
- 5-way Navi key (soft keys, send and end)
- Side-keys for volume up and down and camera capture

Hardware features

- Main camera: 5 megapixel camera with autofocus and integrated flash
- Internal GPS receiver
- MicroUSB connector/charger plug for data transfer (USB 2.0), charging and headset
- High speed USB (FS/HS/OTG)
- 2 mm charger plug interface
- Bluetooth version 2.1
- microSD memory card connector
- Stereo Music Player
- Integrated handsfree speaker
- Active noise cancelling (uplink)
- Internal vibra and antennas
- Plug-in SIM 1.8V and 3.0V, more than 1000 entries

RF features

- GSM/EDGE 850/900/1800/1900

- WCDMA band I, II and VIII
- High speed upload - HSUPA cat 5 (2.0 Mbps)
- High speed download - HSDPA cat 9 (10.2 Mbps)
- EDGE: MSC 32
- GPRS: MSC 32
- HSCSD, CSD for browsing and as data modem

■ Software and user interface features

Selection of software application and features

- OMA DRM 2.0 (Digital Rights Management)/Windows media DRM
- OMA MMS 1.3, MMS Conformance 3.0, AMR, and SMIL
- OMA Client Provisioning 1.1
- SyncML (local and remote)
- Java
- Music Player supporting MP3, MPEG4, AAC, eAAC+, WMA
- OMA DM 1.2 and FOTA with FUMO 1.0
- Calendar with today view in active standby mode
- Instant messaging
- VoIP
- Wideband AMR
- Nokia OSS Internet Browser
- Macromedia Flash Lite 3.0
- Nokia PC suite

■ Accessories

Sales package contents

- Nokia 6700 classic phone
- Nokia Battery BL-6Q
- Nokia High Efficiency Charger AC-8
- Nokia Wired Headset WH-203
- Nokia Micro USB Cable CA-101
- 1 GB MU-22 MicroSD card
- User Guide

Table 1 Battery and chargers

Type	Name
Note: This phone is charged through the smaller Nokia standard charger interface (2.0 mm plug). A 3.5 mm compatible Nokia standard charger can be used together with the CA-44 charger adapter.	
BL-6Q	Battery 960 mAh Li-Ion
AC-8	High efficiency charger
AC-6	USB charger

Table 2 Car accessories

Type	Name
CK-100	Bluetooth car kit
DC-9	Mobile charger
HK-510	Plug-In car kit with display and DSP

Table 3 Headsets

Type	Name
Wired	
WH-203	Stereo headset
Wireless	
BH-606	Bluetooth mono headset
BH-103	Bluetooth stereo headset

Table 4 Cables

Type	Name
CA-101	Micro USB cable

■ Technical specifications

General specifications

Unit	Dimension (mm)	Weight (g)	Volume (cc)
RM-470 transceiver with BL-6Q 960 mAh Li-Ion battery pack	109.8 x 45.0 x 11.1	116	46.5

Main RF characteristics for GSM850/900/1800/1900 and WCDMA band I, II and VIII phones

Parameter	Unit
Cellular system	GSM850, EGSM900, GSM1800/1900, WCDMA I (2100), WCDMA II (1900) and WCDMA VIII (900)
Rx frequency band	GSM850: 869 - 894 MHz
	EGSM900: 925 - 960 MHz
	GSM1800: 1805 - 1880 MHz
	GSM1900: 1930 - 1990 MHz
	WCDMA I (2100): 2110 - 2170 MHz
	WCDMA II (1900): 1930 - 1990
	WCDMA VIII (900): 925- 960 MHz

Parameter	Unit
Tx frequency band	GSM850: 824 - 849 MHz
	EGSM900: 880 - 915 MHz
	GSM1800: 1710 - 1785 MHz
	GSM1900: 1850 - 1910 MHz
	WCDMA I (2100): 1920 - 1980 MHz
	WCDMA II (1900): 1850 - 1910
	WCDMA VIII (900): 880 - 915 MHz
Output power	GSM850: +5 ... +33dBm/3.2mW ... 2W
	GSM900: +5 ... +33dBm/3.2mW ... 2W
	GSM1800: +0 ... +30dBm/1.0mW ... 1W
	GSM1900: +0 ... +30dBm/1.0mW ... 1W
	WCDMA I (2100): -50 ... +21 dBm/0.01μW ... 251.2mW
	WCDMA II (1900): -50 ... +21 dBm/0.01μW ... 251.2mW
	WCDMA VIII (900): -50 ... +21 dBm/0.01μW ... 251.2mW
Number of RF channels	GSM850: 124
	GSM900: 174
	GSM1800: 374
	GSM1900: 299
	WCDMA I (2100): 277
	WCDMA II (1900): 289
	WCDMA VIII (900): 152
Channel spacing	200 kHz
Number of Tx power levels	GSM850: 15
	GSM900: 15
	GSM1800: 16
	GSM1900: 16
	WCDMA I (2100): 75
	WCDMA II (1900): 75
	WCDMA VIII (900): 75

Battery endurance

Battery	Talk time	Standby time
BL-6Q 960 mAh Li-ion	GSM: up to 5 h WCDMA: up to 4 h	GSM: up to 416 h WCDMA: up to 480 h

Note: Variation in operation times will occur depending on SIM card, network settings and usage. Talk time is increased by up to 30% if half rate is active, and reduced by 5% if enhanced full rate is active.

Environmental conditions

Environmental condition	Ambient temperature	Notes
Normal operation	-15 °C ... +55 °C	Specifications fulfilled
Reduced performance	55 °C ... +70 °C	Operational only for short periods
Intermittent or no operation	-40 °C ... -15 °C and +70 °C ... +85 °C	Operation not guaranteed but an attempt to operate will not damage the phone
No operation or storage	<-40 °C and >+85 °C	No storage. An attempt to operate may cause permanent damage
Charging allowed	-15 °C ... +55 °C	
Long term storage conditions	0 °C ... +85 °C	
Humidity and water resistance		Relative humidity range is 5 to 95%. Condensed or dripping water may cause intermittent malfunctions. Protection against dripping water has to be implemented in (enclosure) mechanics. Continuous dampness will cause permanent damage to the module.

(This page left intentionally blank.)

2 — Service Devices and Service Concepts

(This page left intentionally blank.)

Table of Contents

Service devices.....	2-5
Product specific devices.....	2-5
FS-98.....	2-5
MJ-204.....	2-6
SA-106.....	2-7
SA-131.....	2-7
SS-209.....	2-7
Using SA-131 GPS RF coupler with RM-470.....	2-7
General devices.....	2-8
CU-4.....	2-9
FLS-5.....	2-10
FPS-21.....	2-11
PK-1.....	2-11
PKD-1.....	2-12
RJ-230.....	2-12
SB-6.....	2-12
SRT-6.....	2-12
SS-46.....	2-12
SS-62.....	2-13
SX-4.....	2-13
Cables.....	2-13
CA-101.....	2-13
CA-31D.....	2-14
CA-58RS.....	2-14
CA-89DS.....	2-14
DAU-9S.....	2-15
PCS-1.....	2-15
XRS-6.....	2-15
Service concepts.....	2-16
POS (Point of Sale) flash concept.....	2-16
Flash concept with FPS-21.....	2-17
CU-4 flash concept with FPS-21.....	2-18
Module jig service concept.....	2-19
RF testing concept with RF coupler.....	2-20
Service concept for RF testing and RF/BB tuning.....	2-21
GPS testing concept with GPS RF coupler.....	2-22
Bluetooth testing concept with SB-6.....	2-23

List of Tables

Table 5 Attenuation values	2-14
----------------------------------	------

List of Figures

Figure 2 Using SA-131 with RM-470	2-8
Figure 3 POS flash concept	2-16
Figure 4 Basic flash concept with FPS-21.....	2-17
Figure 5 CU-4 flash concept with FPS-21.....	2-18
Figure 6 Module jig service concept.....	2-19
Figure 7 RF testing concept with RF coupler	2-20


Figure 8 Service concept for RF testing and RF/BB tuning	2-21
Figure 9 RF testing concept with RF coupler	2-22
Figure 10 Service concept for RF testing and RF/BB tuning	2-23

■ Service devices

Product specific devices

The table below gives a short overview of service devices that can be used for testing, error analysis, and repair of product RM-470. For the correct use of the service devices, and the best effort of workbench setup, please refer to various concepts.

	FS-98	Flash adapter	
	• FS-98 is equipped with a clip interlock system • provides standardised interface towards Control Unit • provides RF connection using coupler • multiplexing between USB and FBUS media, controlled by VUSB		



MJ-204



Module jig

MJ-204 is meant for component level troubleshooting.

The jig includes an RF interface for GSM, WCDMA and Bluetooth. In addition, it has the following features:

- Provides mechanical interface with the engine module
- Provides galvanic connection to all needed test pads in module
- Multiplexing between USB and FBUS media, controlled by Vusb
- MMC interface
- Duplicated SIM connector
- Connector for control unit
- Access for AV- and USB connectors

Frequency	Attenuation. (dB)
GSM850 TX	-43.3
GSM850 RX	-39.5
GSM900 TX	-37.2
GSM900 RX	-31.8
GSM1800 TX	-34.0
GSM1800 RX	-29.2
GSM1900 TX	-28.3
GSM1900 RX	-27.0
WCDMA band I TX	-27.0
WCDMA band I RX	-23.8
WCDMA band II TX	-28.3
WCDMA band II RX	-27.0
WCDMA band VIII TX	-37.2
WCDMA band VIII RX	-31.8

	SA-106	RF coupler																															
	SA-106 is an RF coupler for WCDMA and GSM RF testing. It is used together with SS-62.																																
	The following table shows attenuations from the antenna pads of the mobile terminal to the SMA connectors of SA-106:																																
	<table><tr><th>Frequency</th><th>Attenuation. (dB)</th></tr><tr><td>GSM850 TX</td><td>Low:-10.4 Mid:-10.0 High:-10.0</td></tr><tr><td>GSM850 RX</td><td>Low:-9.0 Mid:-8.5 High:-8.5</td></tr><tr><td>GSM900 TX</td><td>Low:-8.5 Mid:-8.5 High:-8.5</td></tr><tr><td>GSM900 RX</td><td>Low:-8.5 Mid:-9.1 High:-10.0</td></tr><tr><td>GSM1800 TX</td><td>Low:-23.7 Mid:-20.0 High:-18.4</td></tr><tr><td>GSM1800 RX</td><td>Low:-18.0 Mid:-17.2 High:-16.7</td></tr><tr><td>GSM1900 TX</td><td>Low:-17.6 Mid:-16.7 High:-16.1</td></tr><tr><td>GSM1900 RX</td><td>Low:-15.8 Mid:-15.1 High:-14.3</td></tr><tr><td>WCDMA band I TX</td><td>Low:-15.9 Mid:-15.3 High:-14.7</td></tr><tr><td>WCDMA band I RX</td><td>Low:-12.3 Mid:-12.2 High:-12.6</td></tr><tr><td>WCDMA band II TX</td><td>Low:-17.5 Mid:-16.7 High:-16.1</td></tr><tr><td>WCDMA band II RX</td><td>Low:-15.8 Mid:-15.1 High:-14.3</td></tr><tr><td>WCDMA band VIII TX</td><td>Low:-8.5 Mid:-8.5 High:-9.2</td></tr><tr><td>WCDMA band VIII RX</td><td>Low:-9.0 Mid:-9.0 High:-9.0</td></tr></table>			Frequency	Attenuation. (dB)	GSM850 TX	Low:-10.4 Mid:-10.0 High:-10.0	GSM850 RX	Low:-9.0 Mid:-8.5 High:-8.5	GSM900 TX	Low:-8.5 Mid:-8.5 High:-8.5	GSM900 RX	Low:-8.5 Mid:-9.1 High:-10.0	GSM1800 TX	Low:-23.7 Mid:-20.0 High:-18.4	GSM1800 RX	Low:-18.0 Mid:-17.2 High:-16.7	GSM1900 TX	Low:-17.6 Mid:-16.7 High:-16.1	GSM1900 RX	Low:-15.8 Mid:-15.1 High:-14.3	WCDMA band I TX	Low:-15.9 Mid:-15.3 High:-14.7	WCDMA band I RX	Low:-12.3 Mid:-12.2 High:-12.6	WCDMA band II TX	Low:-17.5 Mid:-16.7 High:-16.1	WCDMA band II RX	Low:-15.8 Mid:-15.1 High:-14.3	WCDMA band VIII TX	Low:-8.5 Mid:-8.5 High:-9.2	WCDMA band VIII RX	Low:-9.0 Mid:-9.0 High:-9.0
Frequency	Attenuation. (dB)																																
GSM850 TX	Low:-10.4 Mid:-10.0 High:-10.0																																
GSM850 RX	Low:-9.0 Mid:-8.5 High:-8.5																																
GSM900 TX	Low:-8.5 Mid:-8.5 High:-8.5																																
GSM900 RX	Low:-8.5 Mid:-9.1 High:-10.0																																
GSM1800 TX	Low:-23.7 Mid:-20.0 High:-18.4																																
GSM1800 RX	Low:-18.0 Mid:-17.2 High:-16.7																																
GSM1900 TX	Low:-17.6 Mid:-16.7 High:-16.1																																
GSM1900 RX	Low:-15.8 Mid:-15.1 High:-14.3																																
WCDMA band I TX	Low:-15.9 Mid:-15.3 High:-14.7																																
WCDMA band I RX	Low:-12.3 Mid:-12.2 High:-12.6																																
WCDMA band II TX	Low:-17.5 Mid:-16.7 High:-16.1																																
WCDMA band II RX	Low:-15.8 Mid:-15.1 High:-14.3																																
WCDMA band VIII TX	Low:-8.5 Mid:-8.5 High:-9.2																																
WCDMA band VIII RX	Low:-9.0 Mid:-9.0 High:-9.0																																
	SA-131	GPS RF coupler																															
	SA-131 is a RF coupler for GPS testing. It is used together with SS-62.																																
	For more information on how to use the SA-131 with RM-470, see Using SA-131 GPS RF coupler with RM-470 (page 2-7) .																																
	SS-209	Camera removal tool																															

Using SA-131 GPS RF coupler with RM-470

Use the following basic SA-131 setup for RM-470:

- 1575.520152 MHz
- -110 dbm
- 20 db fixed RF attenuator

- 22 db product specific RF attenuation
- And use the following settings for the SA-131:
- Base setting: 3
 - Sledge setting: 2
 - Frame setting: A2
 - Coupler setting: A2
 - Direction: Down




Figure 2 Using SA-131 with RM-470

General devices

The table below gives a short overview of service devices that can be used for testing, error analysis, and repair of product RM-470. For the correct use of the service devices, and the best effort of workbench setup, please refer to various concepts.

CU-4 	CU-4	Control unit	CU-4 is a general service tool used with a module jig and/or a flash adapter. It requires an external 12 V power supply. The unit has the following features: • software controlled via USB • EM calibration function • Forwards FBUS/Flashbus traffic to/from terminal • Forwards USB traffic to/from terminal • software controlled BSI values • regulated VBATT voltage • 2 x USB2.0 connector (Hub) • FBUS and USB connections supported When using CU-4, note the special order of connecting cables and other service equipment: Instructions 1 Connect a service tool (jig, flash adapter) to CU-4. 2 Connect CU-4 to your PC with a USB cable. 3 Connect supply voltage (12 V) 4 Connect an FBUS cable (if necessary). 5 Start Phoenix service software.  Note: Phoenix enables CU-4 regulators via USB when it is started. Reconnecting the power supply requires a Phoenix restart.
--	-------------	---------------------	--

 A black, elongated, rectangular device with a USB cable attached. The device has a label that reads "NOKIA FLS-5" and "Pro Production".	FLS-5	Flash device	
	FLS-5 is a dongle and flash device incorporated into one package, developed specifically for POS use. Note: FLS-5 can be used as an alternative to PKD-1.		

 FPS-21	FPS-21	Flash prommer	
	PK-1	Software protection key	
FPS-21 sales package: • FPS-21 prommer • AC-35 power supply • CA-31D USB cable FPS-21 interfaces: <i>Front</i> • Service cable connector Provides Flashbus, USB and VBAT connections to a mobile device. • SmartCard socket A SmartCard is needed to allow DCT-4 generation mobile device programming. <i>Rear</i> • DC power input For connecting the external power supply (AC-35). • Two USB A type ports (USB1/USB3) Can be used, for example, for connecting external storage memory devices or mobile devices • One USB B type device connector (USB2) For connecting a PC. • Phone connector Service cable connection for connecting Flashbus/FLA. • Ethernet RJ45 type socket (LAN) For connecting the FPS-21 to LAN. <i>Inside</i> • Four SD card memory slots For internal storage memory. Note: In order to access the SD memory card slots inside FPS-21, the prommer needs to be opened by removing the front panel, rear panel and heatsink from the prommer body. Note: FPS-10 can be used for flashing instead of FPS-21 if necessary.			
PK-1 is a hardware protection key with a USB interface. It has the same functionality as the PKD-1 series dongle. PK-1 is meant for use with a PC that does not have a series interface. To use this USB dongle for security service functions please register the dongle in the same way as the PKD-1 series dongle.			

	PKD-1	SW security device	
	RJ-230	Soldering jig	
	SB-6	Bluetooth test and interface box (sales package)	
	SRT-6	Opening tool	
	SS-46	Interface adapter	

SW security device is a piece of hardware enabling the use of the service software when connected to the parallel (LPT) port of the PC. Without the device, it is not possible to use the service software. Printer or any such device can be connected to the PC through the device if needed.

RJ-230 is a soldering jig used for soldering and as a rework jig for the engine module.

The SB-6 test box is a generic service device used to perform Bluetooth bit error rate (BER) testing, and establishing cordless FBUS connection via Bluetooth. An ACP-8x charger is needed for BER testing and an AXS-4 cable in case of cordless interface usage testing .

Sales package includes:

- SB-6 test box
- Installation and warranty information

SRT-6 is used to open phone covers.

Note: The SRT-6 is included in the Nokia Standard Toolkit.

SS-46 acts as an interface adapter between the flash adapter and FPS-20/FPS-21.

	SS-62	Generic flash adapter base for BB5	
	• generic base for flash adapters and couplers • SS-62 equipped with a clip interlock system • provides standardised interface towards Control Unit • provides RF connection using galvanic connector or coupler • multiplexing between USB and FBUS media, controlled by VUSB		
	SX-4	Smart card	
	SX-4 is a BB5 security device used to protect critical features in tuning and testing. SX-4 is also needed together with FPS-20/FPS-21 when DCT-4 phones are flashed.		

Cables

The table below gives a short overview of service devices that can be used for testing, error analysis, and repair of product RM-470. For the correct use of the service devices, and the best effort of workbench setup, please refer to various concepts.

 CA-101 100cm	CA-101	Micro USB cable	
	The CA-101 is a USB-to-microUSB data cable that allows connections between the PC and the phone.		

	CA-31D	USB cable	
	CA-58RS	RF tuning cable	
 CA-89DS 100cm	CA-89DS	Cable	

The CA-31D USB cable is used to connect FPS-20/FPS-21 to a PC. It is included in the FPS-20/FPS-21 sales packages.

Product-specific adapter cable for RF tuning.

- Table 5 Attenuation values**

Band	Attenuation Rx/Tx
GSM850/900	0.2...0.3 dB
GSM1800/1900	0.3...0.4 dB
WCDMA/WLAN	0.4...0.6 dB

Provides VBAT and Flashbus connections to mobile device programming adapters.

	DAU-9S	MBUS cable	
	PCS-1	Power cable	
	XRS-6	RF cable	

	The MBUS cable DAU-9S has a modular connector and is used, for example, between the PC's serial port and module jigs, flash adapters or docking station adapters. Note: Docking station adapters valid for DCT4 products.		
	The PCS-1 power cable (DC) is used with a docking station, a module jig or a control unit to supply a controlled voltage.		
	The RF cable is used to connect, for example, a module repair jig to the RF measurement equipment. SMA to N-Connector approximately 610 mm. Attenuation for: • GSM850/900: 0.3+-0.1 dB • GSM1800/1900: 0.5+-0.1 dB • WCDMA/WLAN: 0.6+-0.1dB		

■ Service concepts

POS (Point of Sale) flash concept




Figure 3 POS flash concept

Type	Description
Product specific tools	
BL-6Q	Battery
Other tools	
FLS-5	POS flash dongle
	PC with Phoenix service software
Cables	
CA-101	Micro USB cable

Flash concept with FPS-21




Figure 4 Basic flash concept with FPS-21

Type	Description
Product specific devices	
FS-98	Flash adapter
Other devices	
FPS-21	Flash prommer box
AC-35	Power supply
PK-1/PKD-1	SW security device
SS-46	Interface adapter
	PC with Phoenix service software
Cables	
CA-89DS	Service cable
	USB cable

CU-4 flash concept with FPS-21




Figure 5 CU-4 flash concept with FPS-21

Type	Description
Product specific devices	
FS-98	Flash adapter
Other devices	
CU-4	Control unit
FPS-21	Flash prommer box
AC-35	Power supply
PK-1/PKD-1	SW security device
SS-62	Flash adapter base
SX-4	Smart card (for DCT-4 generation mobile device programming)
	PC with Phoenix service software
Cables	
PCS-1	Power cable
CA-89DS	Service cable
	Standard USB cable

Type	Description
	USB cable

Module jig service concept




Figure 6 Module jig service concept

Type	Description
Phone specific devices	
MJ-204	Module jig
Other devices	
CU-4	Control unit
FPS-21	Flash prommer box
PK-1/PKD-1	SW security device
SX-4	Smart card
	PC with VPOS and Phoenix service software
	Measurement equipment
Cables	
CA-89DS	Service cable
PCS-1	DC power cable

Type	Description
XRS-6	RF cable
	USB cable
	GPIB control cable

RF testing concept with RF coupler




Figure 7 RF testing concept with RF coupler

Type	Description
Product specific devices	
FS-98	Flash adapter
SA-106	RF coupler
Other devices	
CU-4	Control unit
SX-4	Smart card
FPS-21	Flash prommer box
PK-1/PKD-1	SW security device
SS-62	Flash adapter base
	Measurement equipment
	PC with Phoenix service software

Type	Description
Cables	
CA-89DS	Service cable
PCS-1	Power cable
XRS-6	RF cable
	GPIO control cable
	USB cable

Service concept for RF testing and RF/BB tuning




Figure 8 Service concept for RF testing and RF/BB tuning

Type	Description
Product specific devices	
MJ-204	Module jig
Other devices	
CU-4	Control unit
PK-1/PKD-1	SW security device
SX-4	Smart card
	Measurement equipment

Type	Description
	Smart card reader
	PC with Phoenix service software
Cables	
DAU-9S	MBUS cable
PCS-1	DC power cable
XRS-6	RF cable
	GPIB control cable
	USB cable

GPS testing concept with GPS RF coupler




Figure 9 RF testing concept with RF coupler

Type	Description
Product specific devices	
FS-98	Flash adapter
SA-131	GPS RF coupler
Other devices	
CU-4	Control unit
SX-4	Smart card

Type	Description
JXS-1	RF shield box
PKD-1/PK-1	SW security device
SS-62	Flash adapter base
	Smart card reader
	Measurement equipment
	PC with Phoenix service software
Cables	
CA-58RS	RF service cable (product-specific adapter cable)
PCS-1	Power cable
DAU-9S	MBUS cable
XRS-6	RF cable
	20dB attenuator
	Interface cable
	USB cable

Bluetooth testing concept with SB-6




Figure 10 Service concept for RF testing and RF/BB tuning

Type	Description
Product specific devices	

Type	Description
FS-98	Flash adapter
Other devices	
CU-4	Control unit
SS-62	Flash adapter base
PK-1	SW security device
SX-4	Smart card
SB-6	Bluetooth test and interface box
	Smart card reader
	PC with Phoenix service software
Cables	
DAU-9S	MBUS cable
PCS-1	DC power cable
	USB cable

3 — BB Troubleshooting and Manual Tuning Guide

(This page left intentionally blank.)

Table of Contents

Baseband self tests in Phoenix	3-5
Power and charging troubleshooting	3-7
Dead or jammed device troubleshooting	3-7
Power key troubleshooting	3-9
General voltage checking troubleshooting	3-10
General power checking	3-12
Charging troubleshooting	3-13
USB charging troubleshooting	3-14
Battery current measuring fault troubleshooting	3-15
Clocking troubleshooting	3-16
Interface troubleshooting	3-17
Flash programming fault troubleshooting	3-17
SIM card troubleshooting	3-20
MicroSD card troubleshooting	3-22
USB troubleshooting	3-23
USB data interface troubleshooting	3-23
USB charging troubleshooting	3-25
User interface troubleshooting	3-26
Keyboard and side keys troubleshooting	3-26
Navi key troubleshooting	3-27
Keyboard LEDs and Navi key LEDs troubleshooting	3-28
Accelerometer self test troubleshooting	3-28
Display module troubleshooting	3-31
General instructions for display troubleshooting	3-31
Display fault troubleshooting	3-33
Display backlight troubleshooting	3-33
Ambient light sensor (ALS)	3-35
ALS troubleshooting	3-35
ALS functionality check	3-36
ALS retuning	3-36
GPS troubleshooting	3-38
GPS antenna	3-38
GPS layout and basic test points	3-38
GPS settings for Phoenix	3-39
GPS control	3-39
GPS Quick Test window	3-39
GPS RF test points	3-40
GPS failure troubleshooting	3-41
GPS basic checks troubleshooting	3-42
Camera module troubleshooting	3-44
Introduction to camera troubleshooting	3-44
Camera troubleshooting	3-44
Taking and evaluating test pictures	3-44
Camera troubleshooting	3-45
Camera baseband troubleshooting	3-45
Camera no recognizable viewfinder image troubleshooting	3-47
Camera bad image quality troubleshooting	3-48
Camera flash troubleshooting	3-48
Audio troubleshooting	3-50
Audio troubleshooting test instructions	3-50

Internal earpiece troubleshooting	3-52
Internal microphone troubleshooting	3-52
Internal handsfree (IHF) troubleshooting	3-53
Acoustics troubleshooting	3-54
Introduction to acoustics troubleshooting	3-54
Earpiece troubleshooting	3-55
IHF troubleshooting	3-56
Microphone troubleshooting	3-57
Vibra troubleshooting	3-58
Bluetooth troubleshooting	3-59
Baseband manual tuning guide	3-60
Certificate restoring for BB5 products	3-60
Energy management calibration	3-65

List of Tables

Table 6 Nominal x, y, z readout	3-31
Table 7 Nominal voltages	3-31
Table 8 Display module troubleshooting cases	3-31
Table 9 Pixel defects	3-32
Table 10 Calibration value limits	3-65

List of Figures

Figure 11 Flashing pic 1. Take single trig measurement for the rise of the BSI signal	3-18
Figure 12 Flashing pic 2. Take single trig measurement for the rise of the BSI signal	3-19
Figure 13 Accelerometer axes	3-29
Figure 14 GPS antenna location	3-38
Figure 15 GPS layout and basic test points	3-38
Figure 16 GPS Control dialog box	3-39
Figure 17 GPS Quick Test window for GPS troubleshooting	3-40
Figure 18 GPS RF probe points	3-41
Figure 19 Differential output waveform of the Ext_in_IHF_out out loop measurement when speaker is connected.	3-51


■ Baseband self tests in Phoenix

Context

Always start the troubleshooting procedure by running the Phoenix self tests. If a test fails, please follow the diagram below.

If the phone is dead and you cannot perform the self tests, go to *Dead or jammed device troubleshooting*.


Troubleshooting flow




■ Power and charging troubleshooting

Dead or jammed device troubleshooting

Troubleshooting flow - Page 1 of 2




Troubleshooting flow - Page 2 of 2




Power key troubleshooting

Troubleshooting flow




General voltage checking troubleshooting

Troubleshooting flow - Page 1 of 2



Troubleshooting flow - Page 2 of 2




General power checking

Check the following voltages:

Signal Rename	Regulator	Sleep	Idle	Nominal voltage	Main user	Notes
VIO	Pearl/Gazoo	ON	ON	1.8	Memory, I/Os, Display	
VBACK	Pearl/Gazoo	ON	ON	2.5	Back-up battery	
VSIM1	Pearl/Gazoo	ON	ON	1.8/3.0	SIM card	
VAUX1	Pearl/Gazoo	ON	ON	2.8	TV-OUT, 3DFS, MR, Display	
VAUX2	Pearl/Gazoo	OFF	OFF	2.5	ALS	
VANA	Pearl/Gazoo	ON	ON	2.5	Audio	
VR1	Pearl/Gazoo	OFF	ON	2.5	Crystal oscillators	
VRFC	Pearl/Gazoo	OFF	ON	1.8	RAPU converters	
VRCP1	Pearl/Gazoo			4.75	To RF parts	
VREF	Pearl/Gazoo	ON	ON	1.25	RF reference	
VCORE	Pearl/Gazoo	ON	ON	1.2	RAPU digital	Can change due to RAPU version & SW
VOUT	Pearl/Gazoo	OFF	OFF	2.5	Video switch	
VCAM_2V8	N1421	OFF	OFF	2.8	Camera	Disabled in sleep
VCAM_1V8	N1420	OFF	OFF	1.800	Camera	Disabled in sleep
VMEM	Pearl/Gazoo	OFF	OFF	2.9	microSD	Disabled in sleep

Charging troubleshooting

Troubleshooting flow




USB charging troubleshooting

Context

For instructions regarding USB charging troubleshooting, see section [USB charging troubleshooting \(page 3–25\)](#).


Battery current measuring fault troubleshooting

Troubleshooting flow



Clocking troubleshooting


Troubleshooting flow



■ Interface troubleshooting

Flash programming fault troubleshooting

Troubleshooting flow - Page 1 of 2



Troubleshooting flow - Page 2 of 2





Figure 11 Flashing pic 1. Take single trig measurement for the rise of the BSI signal





Figure 12 Flashing pic 2. Take single trig measurement for the rise of the BSI signal

SIM card troubleshooting


Troubleshooting flow



SIM power-on sequence

Testpoints between
RAPU and EM ASIC
J2218 = SIMData
J2219 = SIMClk
J2220 = SIMIOC

Fsimclk = 3.8MHz



SIM contacts




SIM power-on sequence on X2700.



SIM power-on sequence between RAPU and EM ASIC.

MicroSD card troubleshooting


Troubleshooting flow




USB troubleshooting

USB data interface troubleshooting

Troubleshooting flow - Page 1 of 2




Troubleshooting flow - Page 2 of 2



USB charging troubleshooting

Troubleshooting flow



■ User interface troubleshooting

Keyboard and side keys troubleshooting

Context


Possible failure mode in the keyboard module:

- One or more keys are stuck, so that the key does not react when a keydome or a side key is pressed. This kind of failure is caused by mechanical reasons (dirt, rust, mechanical damage, etc.)

If the failure mode is not clear, start with the Keyboard test in Phoenix.


In this phone the keyboard is connected to RAPU via an I/O Expander. RAPU controls the I/O Expander by the I2C bus.

Troubleshooting flow




Navi key troubleshooting

Troubleshooting flow



Keyboard LEDs and Navi key LEDs troubleshooting

Troubleshooting flow



Accelerometer self test troubleshooting

Context


The accelerometer is sensitive to all vibrations and movements (including those made by IHF and Vibra). Make sure before starting the troubleshooting that there are no vibrations or movements which could have an impact on the analysis.

The three different axes for the accelerometer are illustrated in the picture below.



Figure 13 Accelerometer axes

Troubleshooting flow



Symptoms and diagnosis

Table 6 Nominal x, y, z readout

Position		Nominal readout X	Nominal readout Y	Nominal readout Z
	Phone lying flat on table. Display up.	0.0	0.0	1.0
	Phone lying flat on table. Display down.	0.0	0.0	-1.0
	Holding the phone horizontal	0.0	1.0	0.0
	Holding the phone right side down	-1.0	0.0	0.0

The impact test is done with the phone in four different positions to test all axes. The table presents the nominal value readout value for x, y and z axis in the different phone positions. Tolerance +/- 0.9

Table 7 Nominal voltages

Supply	Measure on	Nominal voltage
VAUX2	C6575 C6576	2.5 V
VIO	C6577	1.8 V

Display module troubleshooting

General instructions for display troubleshooting

Context

- The display is in a normal mode when the phone is in active use.
- The operating modes of the display can be controlled with the help of *Phoenix*.

Table 8 Display module troubleshooting cases

Display blank	There is no image on the display. The display looks the same when the phone is on as it does when the phone is off. The backlight can be on in some cases.
Image on the display not correct	Image on the display can be corrupted or a part of the image can be missing. • If a part of the image is missing, change the display module. • If the image is otherwise corrupted, follow the display fault troubleshooting flowchart.

Backlight dim or not working at all	Backlight LED components are inside the display module. Backlight failure can also be in the connector or in the backlight power source in the main engine of the phone. This means that in case the display is working (image OK), the backlight is faulty.
Visual defects (pixel)	Pixel defects can be checked by controlling the display with Phoenix. Use both colours, black and white, on a full screen. The display may have some random pixel defects that are acceptable for this type of display. The criteria when pixel defects are regarded as a display failure, resulting in a replacement of the display, are presented the following table.

Table 9 Pixel defects


Item		White dot defect				Black dot defect	Total
1	Defect counts	R	G	B	White Dot Total	1	1
		1	1	1	1		
2	Combined defect counts	Not allowed. Two single dot defects that are within 5 mm of each other should be interpreted as combined dot defect.					

Steps

1. Verify with a working display that the fault is not on the display module itself.
The display module cannot be repaired.
2. Check that the cellular engine is working normally.
 - i To check the functionality, connect the phone to a docking station.
 - ii Start *Phoenix* service software.
 - iii Read the phone information to check that also the application engine is functioning normally (you should be able to read the APE ID).
3. Proceed to the display fault troubleshooting flowchart.
Use the **Display Test** tool in *Phoenix* to find the detailed fault mode.


Display fault troubleshooting

Troubleshooting flow



Display backlight troubleshooting


Troubleshooting flow



Ambient light sensor (ALS)

ALS troubleshooting


Troubleshooting flow



ALS functionality check

Steps

1. Connect phone to Phoenix and set the phone (e.g. on the table) so that the amount of ambient light seen by ALS is as stable as possible.
2. Start Phoenix
3. Choose **File -> Scan product**
4. Choose **Testing -> Display Test**
5. Open the **Lights** tab, check Ambient Light Sensor check box, click **Read**, cover the sensor and click **Read** again. When covered, Luminance reading should be less than after clicking **Read** without covering the sensor.
6. If component doesn't give any reading or reading doesn't change when sensor is/is not covered, replace the part.



Note: After replacing the ALS. If calibration values of the new sensor are lost or for some other reason, ALS re-tuning is required (see instructions later in this document).

When doing the ALS calibration procedure, it is required to have a reference phone, which includes calibrated ALS. ALS re-tuning instructions show why the reference phone is needed.

ALS retuning

Steps

1. Connect reference phone to *Phoenix* and set the phone (e.g. on the table) so that the amount of ambient light seen by ALS is as stable as possible.
2. Start *Phoenix*.
3. Choose **File→Scan Product**.

4. Choose **Tuning -> Ambient Light Sensor Calibration**. You should see the following window

Ambient Light Sensor Calibration

☐ Use default values only

Channel 0

Reference Level: 15

AD-Count: 6311

Co-efficient: 0.9619

Channel 1

Reference Level: 158

AD-Count: 666

Co-efficient: 0.0000

Read Calibrate Write

Close Help

5. Read AD-count values for Channel 0 and Channel 1 by click Read button and write them down.
6. Repeat 1-5 for the phone to be calibrated and make sure the phone to be calibrated is located in the same place as reference phone was when luminance reading was taken.
7. Calculate co-efficient from reference phone and phone to be calibrated AD-count values by division: Co-efficient = AD-count(reference phone) / AD-count(phone to be calibrated), write down the calculated co-efficient values.
8. -> Iterate by changing Channel 0 and Channel 1 (reference level) values (remove cross from 'Use default values only'). After writing some value to Channel 0 and Channel 1 (reference value), calibrate button must be pressed. Stop iterating when Co-efficient is equal to Co-efficient calculated in bullet 7. Note that decimal numbers should be used in the iteration in order to achieve enough precision (e.g. 200.2455)
9. After having same Co-efficient value in "Co-efficient" textbox as the calculated value, make sure that ambient light values (read using **Testing -> Display Test -> "Luminance"** textbox) are almost the same in reference phone and calibrated phone. Remember that illuminance readings for reference and calibrated phones must be done in the same ambient light conditions. If illuminance values differs a lot (difference max. +/- 10%), repeat whole ALS re-tuning procedure.
10. To end the calibration, click **Close**.

■ GPS troubleshooting

GPS antenna

The GPS antenna is covering the GPS band. The GPS antenna consists of an antenna flex assembled directly onto the A-cover and connects with a pogo pin onto a pad on the top flex.




Figure 14 GPS antenna location

GPS layout and basic test points




Figure 15 GPS layout and basic test points

VBat, ASIC internal LDO voltages, and clocks are available as shown in figure above.

GPS settings for Phoenix

GPS control

Context

Use the following to test GPS using Phoenix.

Steps

1. Start Phoenix service software.
2. From the **File** menu, select **Scan Product** and check that the correct product version is displayed.
3. From the **Testing** menu, select **GPS Control**. This opens up *GPS Control* dialogue box, as shown in the figure below, and enables the GPS.




Figure 16 GPS Control dialog box

Select **Receiver On** to confirm the GPS is enabled and is in idle mode; at this point all clocks should be present, GPS_En_Reset & SleepX should be high, and Vdd_Dig, Vcc_TCXO & Vcc_PLL/VCO will be present.

Receiver On turns on all RF sections of the ASIC and so all LDOs will be on. These checks are part of [GPS basic checks troubleshooting \(page 3-0 \)](#).

GPS Quick Test window

The *GPS Quick Test* window has all the necessary functionality for GPS troubleshooting. Ensure the test setup is correct and click **Start Test**. (Select **Help** for further information).

This test will perform three tests in one; Self Test, Oscillator Test and CW Test, and will provide a Pass/Fail response. The *GPS Quick Test* window also contains a **Receiver On** button. These checks are part of [GPS failure troubleshooting \(page 3-41\)](#).




Figure 17 GPS Quick Test window for GPS troubleshooting

GPS RF test points

Checking for a connection between these two test points will confirm that the antenna is working correctly, as well as performing a radiated CW test.

J6280 = GPS Ant

J7451 = GPS Ant Gnd

In order to probe GPS RF test points, inject 1575.52 MHz tone @ -110dBm at the GPS antenna test connector and select **Receiver On**, then probe the GPS RF test points as shown in figure "GPS RF probe points". Compare RF levels with a known reference phone.





Figure 18 GPS RF probe points

GPS failure troubleshooting

Context


GPS troubleshooting is broken down into two parts: general GPS failure troubleshooting and GPS basic checks troubleshooting. The GPS failure troubleshooting flow can be followed and, where applicable, will feed into the GPS basic checks troubleshooting flow.

Troubleshooting flow



GPS basic checks troubleshooting

Troubleshooting flow



■ Camera module troubleshooting

Introduction to camera troubleshooting

Bad conditions often cause bad pictures. Therefore, the camera operation has to be checked in constant conditions or by using a second, known-to-be-good Nokia device as reference. Image quality is hard to measure quantitatively, and the difference between a good and a bad picture can be small. Some training or experience may be needed to detect what is actually wrong.

When checking for possible errors in camera functionality, knowing what error is suspected significantly helps the testing by narrowing down the amount of test cases. The following types of image quality problems are common:

- Dust (black spots)
- Lack of sharpness
- Bit errors

Camera troubleshooting

Taking and evaluating test pictures

When *taking* a test picture, remember the following:


- Avoid bright fluorescent light, 50/60Hz electrical network or high artificial illumination levels
- If the phone is hot, let it rest for a while before taking the picture
- Make sure the optical system is clean
- Use highest possible resolution
- Make sure the light is sufficient (bright office lightning)
- Do not take the picture towards a light source
- Hold the phone as still as possible when taking the picture
- If camera has auto focus: Pictures should be taken both at infinity $\sim >2\text{m}$ and at macro distance $\sim 10\text{-}15\text{ cm}$ in order to verify auto focus functionality

When *evaluating* a test picture, remember the following:

- The center of the picture is sharper than the edges
- The image may be blurred, though it does not show in the viewfinder
- Analyse the picture from your PC monitor, full colour setting is recommended
- If possible, compare with a picture of the same motive taken with a similar Nokia device
- If camera has auto focus: Remember that the white focussing frame which appears when the camera button is pressed halfway down, must turn green for auto focus lock. If the frame turns red, the camera is not focussed!


Camera troubleshooting

Troubleshooting flow




Camera baseband troubleshooting

Troubleshooting flow




Camera no recognizable viewfinder image troubleshooting

Troubleshooting flow



Camera bad image quality troubleshooting

Troubleshooting flow




Camera flash troubleshooting

Context

Note: Before checking flash functionality, make sure that the camera is working ok.

Troubleshooting flow



■ Audio troubleshooting

Audio troubleshooting test instructions

Differential external earpiece and internal earpiece outputs can be measured either with a single-ended or a differential probe.

When measuring with a single-ended probe each output is measured against the ground.

Internal handsfree output is measured using a current probe, if a special low-pass filter designed for measuring a digital amplifier is not available. Note also that when using a current probe, the input signal frequency must be set to 2kHz.

The input signal for each loop test can be either single-ended or differential.

Required equipment

The following equipment is needed for the tests:

- Oscilloscope
- Function generator (sine waveform)
- Phoenix service software
- Battery voltage 3.7V

Test procedure

Audio can be tested using the Phoenix audio routings option. These different audio loop paths can be activated:

- Mic2P to Internal earpiece
- Mic2P microphone to Internal handsfree speaker

Each audio loop sets routing from the specified input to the specified output enabling a quick in-out test. Loop path gains are fixed and they cannot be changed using Phoenix. Correct pins and signals for each test are presented in a table in the following section.

Phoenix audio loop tests and test results


The results presented in this table apply when no accessory is connected and battery voltage is set to 3.7V.

Earpiece, internal microphone and speaker are in place during measurement. Applying a headset accessory during measurement causes a significant drop in measured quantities.

The gain values presented in the table apply for a differential output vs. single-ended/differential input.

Loop test	Input terminal	Output terminal	Path gain [dB] (fixed)	Input voltage [mVp-p]	Differential output voltage [mVp-p]	Output DC level [V]	Output current [mA]
External Mic to Internal Earpiece	testpad J2101	EarP and EarN	~9	100	288	NA	NA
External Mic to Internal handsfree	testpad J2101	B2170 pads	~16	100	600	NA	NA

Measurement data




If a special low-pass filter designed for measuring digital amplifiers is unavailable, the measurement must be performed with a current probe and the input signal frequency must be 2kHz.

Figure 19 Differential output waveform of the Ext_in_IHF_out out loop measurement when speaker is connected.


Internal earpiece troubleshooting

Troubleshooting flow




Internal microphone troubleshooting

Troubleshooting flow



Internal handsfree (IHF) troubleshooting

Troubleshooting flow



Acoustics troubleshooting

Introduction to acoustics troubleshooting


Acoustics design ensures that the sound is detected correctly with a microphone and properly radiated to the outside of the device by the speaker. The acoustics of the phone include three basic systems: earpiece, integrated handsfree (IHF) and dual microphone (for noise cancelling).

The sound reproduced from the earpiece radiates through a single hole on the front cover (A-cover). The sound reproduced from the IHF speaker radiates from the sound hole located on the back side on the top part of the phone. The inlets for the 2 microphones are found in the bottom and next to the capture key, respectively.

For a correct functionality of the phone, all sound holes must be always open. When the phone is used, care must be taken not to close any of those holes with a hand or fingers. The phone should be dry and clean, and no objects must be located in such a way that they close any of the holes.


Earpiece troubleshooting

Troubleshooting flow




IHF troubleshooting

Troubleshooting flow




Microphone troubleshooting

Troubleshooting flow




Vibra troubleshooting

Troubleshooting flow



Bluetooth troubleshooting

Troubleshooting flow



■ Baseband manual tuning guide

Certificate restoring for BB5 products

Context

This procedure is performed when the device certificate is corrupted for some reason.

All tunings (RF & Baseband, UI) must be done after performing the certificate restoring procedure.

The procedure for certificate restoring is the following:

- Flash the phone with the latest available software using FPS-20 or FPS-21.

Note: USB flashing does not work for a dead BB5 phone.

- Create a request file.
- Send the file to Nokia by e-mail. Use the following addresses depending on your location:
 - APAC: sydney.service@nokia.com
 - CHINA: repair.ams@nokia.com
 - E&A: salo.repair@nokia.com
 - AMERICAS: fls1.usa@nokia.com
- When you receive a reply from Nokia, carry out certificate restoring.
- Tune the phone completely.

Note: SX-4 smart card is needed.

- If the phone resets after certificate restoring, reflash the phone again.

Required equipment and setup:

- Phoenix* service software v 2008.34/38 or newer.
- The latest phone model specific *Phoenix* data package.
- PKD-1 dongle
- SX-4 smart card (Enables BB5 testing and tuning features)
- Activated FPS-20 flash prommer **OR** FPS-21 flash prommer
- Flash update package 08.30.012 or newer for FPS-20 or FPS-21 flash prommers
- CU-4 control unit
- USB cable from PC USB Port to CU-4 control unit
- Phone model specific adapter for CU-4 control unit
- PCS-1 cable to power CU-4 from external power supply
- XCS-4 modular cable between flash prommer and CU-4

Note: CU-4 must be supplied with +12 V from an external power supply in all steps of certificate restoring.


Steps

1. Program the phone software.

- i Start *Phoenix* and login. Make sure the connection has been managed correctly for FPS-20 or FPS-21.
- ii Update the phone MCU software to the latest available version.


If the new flash is empty and the phone cannot communicate with *Phoenix*, reflash the phone.

- iii Choose the product manually from **File**→**Open Product** , and click **OK**.
Wait for the phone type designator (e.g. "RM-1") to be displayed in the status bar.
- iv Go to **Flashing**→**SW Update** and wait until *Phoenix* reads the product data as shown in the following picture.



Product	is automatically set according to the phone support module which was opened manually, but the flash files cannot be found because the correct data cannot be read from the phone automatically.
Code	must be chosen manually, it determines the correct flash files to be used. Please choose the correct product code (can be seen in the phone type label) from the dropdown list.
Flash Type	must be set to Phone as Manufactured .

- v To continue, click **Start**.
Progress bars and messages on the screen show actions during phone programming, please wait.



Programming is completed when Flashing Completed message is displayed.


The product type designator and MCU SW version are displayed in the status bar.

vi Close the *SW Update* window and then choose **File→Close Product**.


2. Create a *Request* file.

For this procedure, you must supply +12 V to CU-4 from an external power supply.


- i To connect the phone with *Phoenix*, choose **File→Scan Product**.
- ii Choose **Tools→Certificate Restore**.
- iii To choose a location for the request file, click **Browse**.



- iv Name the file so that you can easily identify it, and click **Open**.




The name of the file and its location are shown.




- v To create the *Request* file, click **Start**.
 - vi When the file for certificate restore has been created, send it to Nokia as an e-mail attachment.
3. Restore certificate.
- For this procedure, you must supply +12 V to CU-4 from an external power supply.
- i Save the reply file sent by Nokia to your computer.
 - ii Start *Phoenix* service software.
 - iii Choose **File**→**Scan Product**.

- iv From the **Tools** menu, choose **Certificate Restore** and select **Process a response file** in the *Action* pane.




- v To choose the location where response file is saved, click **Browse**.
- vi Click **Open**.



The name of the file and the path where it is located are shown.

- vii To write the file to phone, click **Start**.



Next actions

After a successful rewrite, you must retune the phone completely by using *Phoenix* tuning functions.

Important: Perform all tunings: RF, BB, and UI.

Energy management calibration

Prerequisites

Energy Management (EM) calibration is performed to calibrate the setting (gain and offset) of AD converters in several channels (that is, **battery voltage**, **BSI**, **battery current**) to get an accurate AD conversion result.

Hardware setup:

- An external power supply is needed.
- Supply 12V DC from an external power supply to CU-4 to power up the phone.
- The phone must be connected to a CU-4 control unit with a product-specific flash adapter.

Steps

1. Place the phone to the docking station adapter (CU-4 is connected to the adapter).
2. Start *Phoenix* service software.
3. Choose **File**→ **Scan Product**.
4. Choose **Tuning**→**Energy Management Calibration**.
5. To show the current values in the phone memory, click **Read**, and check that communication between the phone and CU-4 works.
6. Check that the **CU-4 used** check box is checked.
7. Select the item(s) to be calibrated.

Note: ADC calibration has to be performed before other item(s). However, if all calibrations are selected at the same time, there is no need to perform the ADC calibration first.

8. Click **Calibrate**.

The calibration of the selected item(s) is carried out automatically.

The candidates for the new calibration values are shown in the *Calculated values* column. If the new calibration values seem to be acceptable (please refer to the following "Calibration value limits" table), click **Write** to store the new calibration values to the phone permanent memory.

Table 10 Calibration value limits

Parameter	Min.	Max.
ADC Offset	-30	+40
ADC Gain	12000	14000
BSI Gain	1100	1350
VBAT Offset	2635	2755
VBAT Gain	14900	15900
VCHAR Gain	N/A	N/A
IBAT (ICal) Gain	7750	12250

9. Click **Read**, and confirm that the new calibration values are stored in the phone memory correctly. If the values are not stored to the phone memory, click **Write** and/or repeat the procedure again.
10. To end the procedure, close the *Energy Management Calibration* window.

(This page left intentionally blank.)

4 — RF troubleshooting

(This page left intentionally blank.)

Table of Contents

General RF troubleshooting	4-5
Introduction to RF troubleshooting	4-5
RF key components	4-6
Auto tuning	4-6
Introduction to auto tuning	4-6
Auto tuning procedure	4-7
Self test troubleshooting	4-7
Phoenix self test troubleshooting	4-7
Receiver troubleshooting	4-9
Introduction to receiver (RX) troubleshooting	4-9
GSM RX chain activation for manual measurements/GSM RSSI measurement	4-9
GSM receiver troubleshooting flowchart	4-10
WCDMA RX chain activation for manual measurement	4-11
WCDMA RSSI measurement	4-12
WCDMA receiver troubleshooting flowchart	4-13
Transmitter troubleshooting	4-14
Introduction to transmitter (TX) troubleshooting	4-14
GSM transmitter troubleshooting	4-14
GSM transmitter troubleshooting flowchart	4-18
WCDMA transmitter troubleshooting	4-18
WCDMA transmitter troubleshooting flowchart	4-22
Troubleshooting with RF-shield removed	4-23
Introduction	4-23
Voltage checking	4-23
VCTCX0 troubleshooting	4-26
RF component reference	4-26
Antenna	4-29
Antenna overview	4-29
Main antenna functionality	4-29
Antenna troubleshooting	4-29

List of Figures

Figure 20 RF key components	4-6
Figure 21 Auto tuning concept with CMU200	4-7
Figure 22 Phoenix RSSI Reading window	4-9
Figure 23 Phoenix Rx Control window with sample settings (WCDMA band I)	4-11
Figure 24 Phoenix Rx Power Measurement window	4-12
Figure 25 Phoenix RF Controls window	4-14
Figure 26 Typical readings	4-16
Figure 27 Phoenix WCDMA Tx control window	4-19
Figure 28 Typical readings	4-21
Figure 29 Phoenix WCDMA Tx Control window settings	4-24
Figure 30 Test points for voltage checking	4-25
Figure 31 Component reference block diagram	4-28
Figure 32 Antenna contacts	4-29
Figure 33 Antenna switch related components	4-30

(This page left intentionally blank.)

■ General RF troubleshooting

Introduction to RF troubleshooting

Most RF semiconductors are static discharge sensitive

ESD protection must be applied during repair (ground straps and ESD soldering irons).

Pre-baking

These parts are moisture sensitive and must be pre-baked prior to soldering:

- VAP AUS RFIC (N7500)
- TX FEM (N7520)
- WCDMA PA (N7540)
- Aura DC/DC converter (N7560)

Discrete components

In addition to the key components, there are a number of discrete components (resistors, inductors and capacitors) for which troubleshooting is done mainly by *visual inspection*.

Capacitors: check for short circuits.

Resistors: check value with an ohm meter.

Note: In-circuit measurements should be evaluated carefully.

Measuring equipment

All measurements should be done using:

- Module jig MJ-204
- Flash adapter FS-98
- Control unit CU-4/Interface adapter SS-46
- An oscilloscope for low frequency and DC measurements. Recommended probe: 10:1, 10MΩ/8pF.
- A radio communication tester including RF generator and spectrum analyser, for example Rohde & Schwarz CMU200. (Alternatively a spectrum analyser and a RF generator can be used. However, some tests in this guide are not possible to perform if this solution is chosen).

Note: A mobile phone WCDMA transmitter should never be tested with full TX power (only if it is possible to perform the measurement in a good RF-shielded room). Even low power WCDMA transmitters may disturb nearby WCDMA networks and cause problems to 3G cellular phone communication in a wide area.

Note: All measurements with an RF coupler should be performed in an RF-shielded environment because nearby base stations can disturb sensitive receiver measurements. If there is no possibility to use RF shielded environment, testing at frequencies of nearby base stations should be avoided.

Level of repair

The scope of this guideline is to verify functionality of the cellular RF block without removing RF shield.

Instructions for finding the faulty component are provided in some cases, but the whole RF block still needs to be replaced even when a single component is faulty.

Top side



- PC (Windows 2000/XP) with GPIB card
- PK-1/PDK-1 service dongle
- Power supply
- Product specific module jig
- Cables: RF cable XRS-6, USB cable, GBIP cable and MBUS cable DAU-9S
- Signal analyser (TX), signal generator (RX) and RF-splitter or one device including all.




Figure 21 Auto tuning concept with CMU200

Auto tuning procedure

Prerequisites

Install the phone-specific data package, e.g. *Nokia_firmware_RM_470_xxx_v1.00.exe*.

The data package defines the phone-specific settings.

Steps

1. Make sure the phone (in the jig) is connected to the equipment. Else, some menus will not be shown in Phoenix.
2. Go to loss settings by selecting **Tuning (Alt_U)→SET LOSS** from the menu.
3. Set the loss between CMV200 and the phone. (Total loss = cable + jig)
4. Go to auto tuning by selecting **Tuning (Alt_U)→Auto-tune (Alt_A)** from the menu.
5. Start auto tuning by clicking the **Tune** button.

■ Self test troubleshooting

Phoenix self test troubleshooting


Context

Always start the troubleshooting procedure by running the Phoenix self tests. If a test fails, please follow the diagram below.

If the phone is dead and you cannot perform the self tests, go to [Dead or jammed device troubleshooting \(page 4–7\)](#) in chapter 3, Baseband troubleshooting and manual tuning guide.

Note: Self tests are recommended to be made when phone is in jig and a 50Ω load connected to the RF connector. Otherwise power tests may fail depending on antenna load

Troubleshooting flow



■ Receiver troubleshooting

Introduction to receiver (RX) troubleshooting

RX can be tested by making a phone call or in local mode. For the local mode testing, use Phoenix service software.

The main RX troubleshooting measurement is RSSI reading. This test measures the signal strength of the received signal. For GSM RSSI measurements, see section [GSM RX chain activation for manual measurements/GSM RSSI measurement \(page 4–9\)](#) . For a similar test in WCDMA mode, see section [WCDMA RSSI measurement \(page 4–12\)](#).

The RX path for GSM and WCDMA are using the same filters in some bands. Please refer to [RM-470 RF components reference \(page 4–26\)](#) for details.

GSM RX chain activation for manual measurements/GSM RSSI measurement

Prerequisites

Make the following settings in signal generator and Phoenix service software:

Setting	GSM850	GSM900	GSM1800	GSM1900
Phoenix Channel	190	37	700	661
Signal generator to antenna connector	881.46771MHz (67.71kHz offset) at -60dBm	942.46771MHz (67.71kHz offset) at -60dBm	1842.86771MHz (67.71kHz offset) at -60dBm	1960.06771MHz (67.71kHz offset) at -60dBm

Steps

1. Set the phone to local mode.
2. Activate RSSI reading in Phoenix by selecting **Testing→GSM→RSSI reading** .




Figure 22 Phoenix RSSI Reading window


Results

The reading should reflect the level of the signal generator (minus losses) ± 5 dB.

When varying the level in the range -30 to -102dBm the reading should then follow within ± 5 dB.

GSM receiver troubleshooting flowchart

Troubleshooting flow



WCDMA RX chain activation for manual measurement

Steps

1. In Phoenix, select **Testing**→**WCDMA**→**Rx Control** . The Phoenix Rx Control window opens.




Figure 23 Phoenix Rx Control window with sample settings (WCDMA band I)

2. Make settings for the band to be tested according to the following table:

Band to be tested	Phoenix Channel	Signal generator to antenna connector
WCDMA I	10700	2141.0MHz
WCDMA II	9800	1961.0MHz
WCDMA VIII	3013	943.6MHz

3. Make the following general settings (the same values for all bands):

Setting	Value
AGC Mode	Algorithm
AFC Algorithm	OFF
AFC DAC	1024

4. Click **Start** to activate the settings.

If the settings are changed later on (for example, change of channel) you have to click **Stop** and **Start** again.

Note: Clicking **Stop** also disables TX control if it was active.

WCDMA RSSI measurement

Prerequisites

WCDMA RX must be activated before RSSI can be measured. For instructions, please refer to [WCDMA RX chain activation for manual measurement \(page 4-11\)](#).

Connect signal generator to RF connector and use appropriate frequency for each channel.

Steps

1. In Phoenix select **Testing**→**WCDMA**→**RX Power measurement** . The Rx Power Measurement window opens.





Figure 24 Phoenix Rx Power Measurement window

2. In the RX Power measurement window, select:
 - Mode: RSSI
 - Continuous mode
3. Click **Start** to perform the measurement.

Note: WCDMA RSSI measurement is accurate only with WCDMA modulated signal.

WCDMA receiver troubleshooting flowchart

Troubleshooting flow



■ Transmitter troubleshooting

Introduction to transmitter (TX) troubleshooting

Please note the following before performing transmitter tests:

- TX troubleshooting requires TX operation.
- Do not transmit on frequencies that are in use!
- The transmitter can be controlled in local mode for diagnostic purposes.
- The most useful Phoenix tool for GSM transmitter testing is "RF Control"; in WCDMA transmitter testing the best tool is "TX Control".
- Remember that re-tuning is not a fix! Phones are tuned correctly in production.
- The RX path for GSM and WCDMA are using the same filters in some bands. Please refer to [RM-470 RF components reference \(page 4–26\)](#) for details.

Note: Never activate the GSM or WCDMA transmitter without a proper antenna load. Always connect a 50Ω load to the RF connector (antenna, RF-measurement equipment or at least a 2W dummy load); otherwise the GSM or WCDMA Power amplifier (PA) may be damaged.

GSM transmitter troubleshooting

Steps

1. Set the phone to local mode.
2. In Phoenix, select **Testing**→**GSM**→**Rf Controls** . The RF Controls window opens.




Figure 25 Phoenix RF Controls window

3. Make the following settings:

Setting	Value
Active Unit	Tx
Rx/Tx Channel	37
Band	GSM 900
AFC	-28
Operation Mode	Burst
Edge	Off
Tx Data Type	Random
Tx PA Mode	High
Tx Power Level	5

4. Check the basic TX parameters, using a communication analyser (e.g. CMU200).
- Power
 - Phase error
 - Modulation
 - Switching spectrum




Figure 26 Typical readings


5. Change the power level in RF controls window and make sure the power reading follows accordingly.

Next actions

You can troubleshoot the GSM transmitter for each GSM band separately, one band at a time. If you want to troubleshoot GSM850, GSM1800 or GSM1900, change the band in the RF controls window and set the communication analyser accordingly.

GSM transmitter troubleshooting flowchart

Troubleshooting flow



WCDMA transmitter troubleshooting

Steps

1. Set the phone to local mode.
2. In Phoenix, select **Testing**→**WCDMA**→**Tx control** . The Tx Control window opens.




Figure 27 Phoenix WCDMA Tx control window

3. Make settings for the band to be tested, according to the following table:

Band	Channel
WCDMA I	9750
WCDMA II	9400
WCDMA VIII	2788

4. Make the following general settings (the same values for all bands). Note that Max power limit is not checked by default.

Setting	Value
DPDCH enabled	Checked
Max power limit	Checked
Start Rx	Checked
Start level	24
Step size	0
Step count	0
Sequency	0
Step duration	2550
Code class	LONG
Code	16
DPDCH code	0
Weight	15
Code class	2
DPCCH code	0
Weight	8
Code class	2


Note: Use the **Start level** option to set the TX power level.

5. Click **Send** to enable the settings and activate TX.


If settings are changed (eg. new channel selected), you have to click **RF Stop** and **Send** again.

6. Check the basic TX parameters using a communication analyser (e.g. CMU200).


Power



Spectrum - Emission Mask



Spectrum - ACLR (FFT/OBW)



Spectrum - ACLR (Filter)





Figure 28 Typical readings

WCDMA transmitter troubleshooting flowchart

Troubleshooting flow



■ Troubleshooting with RF-shield removed

Introduction

The RF-shield should not be removed in order to replace single components on the RF block. This chapter only assists in locating the faulty component for statistical purposes.

Voltage checking

Steps

1. Set up the main board in the module jig. The phone should be in local mode.
2. Check the following:

TP#	Signal name	Test point	Voltage (all bands)
1	VCTCX0 (G7500) supply	C7501	2.5V
2	RFIC Vapaus (N7500) supply from DC/DC converter	C7570	2.8V
3	TXFEM (N7520) supply from DC/DC converter	C7521	1.3V-3.8V (only when transmitting and depends on output power).
4	WCDMA PA (N7540) supply from DC/DC converter	C7528	0.7V-3.1V (only when transmitting and depends on output power). The value will be 3.1V when settings as described in the note below are used.
5	Vbat at WCDMA PA (N7540)	C7512	3.7V (Vbattery)
6	Supply input to DC/DC conv	C7527	3.7V (Vbattery)

Note: When using settings as shown in the following Tx Control window, the result at TP4 should be 3.1V.




Figure 29 Phoenix WCDMA Tx Control window settings





Figure 30 Test points for voltage checking

VCTCXO troubleshooting

Troubleshooting flow



RF component reference

Component reference table

This table shows the components used for the different bands. It can be used as a reference when troubleshooting which components may or may not be faulty.

	GSM850		GSM900		GSM1800		GSM1900		WCDMA1		WCDMA2		WCDMA8	
Reference	RX	TX	RX	TX	RX	TX	RX	TX	RX	TX	RX	TX	RX	TX
G7500	X	X	X	X	X	X	X	X	X	X	X	X	X	X
L7500	X	X	X	X	X	X	X	X	X	X	X	X	X	X
N7500	X	X	X	X	X	X	X	X	X	X	X	X	X	X
N7520	X	X	X	X	X	X	X	X	X	X	X	X	X	X
N7540										X		X		X
N7560	X	X	X	X	X	X	X	X	X	X	X	X	X	X
T7520						X		X						
Z7521	X				X									
Z7523		X		X										
Z7540							X				X	X		
Z7541									X	X				
Z7542			X										X	X
Z7543										X		X		
Z7544														X

X means that the component is used for the band in the current column.

For further reference, see Component reference schematics on the following page.

Figure 31 Component reference block diagram

■ Antenna

Antenna overview

The phone has one antenna module. The antenna module is covering GSM and WCDMA bands along with GPS and BT. The antenna module consists of a antenna carrier and an LDS antenna, where the antenna pattern is directly deposited on the antenna carrier.

The antenna module also acts as IHF chamber, and contains a speaker and an earpiece. The main antenna has one feed pad for GSM and WCDMA, one feed pad for GPS, one feed pad for BT, one antenna switch pad and two ground pads. All six pads connect to C-springs mounted on the AV-flex.

Main antenna functionality

The antenna module is functioning normally when all six contact pads take proper contact to the C-springs on the AV-flex, and the antenna pattern is electrically intact.

The main antenna functionality must also be checked by measuring the transmitted power with RF coupler at GSM900 channel 124.

Antenna troubleshooting

Antenna contacts, visual check

The antenna module has one feed pad for GSM and WCDMA, one feed pad for GPS, one feed pad for BT, one antenna switch pad and two ground pads. Check that all pads take proper contact to the C-clips on the AV-flex.

Antenna matching components and antenna switch related components, visual check

There is one filtering component on GSM/WCDMA feed, two matching components on GPS feed and two matching components on BT feed. There are also 20 antenna switch related components located at the antenna switch connection and next to the antenna switch.

All matching and antenna switch related components are soldered on the AV-flex. Check visually that all components are properly soldered on the AV-flex. In the case of damage you need to replace the AV-flex.




Figure 32 Antenna contacts




Figure 33 Antenna switch related components

5 — System Module

(This page left intentionally blank.)

Table of Contents

Introduction	5-5
Phone description	5-5
Energy management	5-9
Battery and charging	5-9
Normal and extreme voltages	5-10
Power key and system power-up	5-11
Modes of operation	5-11
Clocking scheme	5-11
Power distribution	5-12
SIM interface	5-13
MicroSD card interface	5-13
USB	5-14
USB interface	5-14
MicroUSB connector	5-14
User interface	5-15
Display interface	5-15
Keyboard interface	5-15
Ambient light sensor (ALS) interface	5-16
Accelerometer	5-16
GPS interface	5-17
Camera interface	5-17
Audio interface	5-18
Bluetooth interface	5-19
RF description	5-19
Receiver (RX)	5-19
Transmitter (TX)	5-20

List of Tables

Table 11 Nominal voltages	5-10
---------------------------------	------

List of Figures

Figure 34 Battery pin order	5-9
Figure 35 Blade battery connector	5-9
Figure 36 Small (right) and wide (left) charger plugs	5-10
Figure 37 Power distribution diagram	5-12
Figure 38 SIM interface	5-13
Figure 39 MicroSD card interface	5-13
Figure 40 USB interface	5-14
Figure 41 MicroUSB connector	5-15
Figure 42 Display interface	5-15
Figure 43 Keyboard interface	5-16
Figure 44 Ambient light sensor (ALS) interface	5-16
Figure 45 GPS interface	5-17
Figure 46 Camera interface	5-18
Figure 47 Audio interface	5-18
Figure 48 Bluetooth interface	5-19

(This page left intentionally blank.)

■ Introduction

Phone description


RAPU is the main digital baseband ASIC in the phone. It contains functionality for both WCDMA and GSM EDGE. Gazoo (N2200) is main audio and energy management controller for the phone.

Key components


Function	Description	Item ref
Main PWB	2rwa	
Ant A/V flex	2rwb	
UI flex	2rwc	
USB Interposer	2rwd	
Display flex	2rwe	
Baseband ASIC	EM ASIC Gazoo	N2200
RF ASIC	VAP AUS	N7500
Processor	RAPU	D2800
GSM PA	Front end module (FEM), quad band	N7520
WCDMA PA		N7540
Oscillators	VCTCXO Balun GSM	G7500 T7520
Memory	Combo 512 M DDR + 1 M M3 (stacked with RAPU)	D3000
Back-up battery	RTC back-up battery 311	G2200
Bluetooth	BTHFMRDS2.1M module	D6000
GPS	GPS receiver	N6200
USB	USB tranceiver	D3300
Accelerometer		N6575
Battery	BL-6Q	
Battery connector	Tabby blade interface	X2070
MicroSD connector		X3200
BTB connectors	Ant A/V	X1500
	UI	X1600
	Display	X2400
RF connector		X7400
SIM connector		X2700
Charging connector		X2000

Key component placement


Top side




Bottom side



System module block diagram



Board and module connections



■ Energy management

Battery and charging

BL-6Q battery

The phone is powered by a 3-pole BL-6Q 960 mAh battery (Li-Ion). The three poles of the battery are named VBAT, BSI and GND, where the BSI line is used to recognize the battery capacity. This is done by means of an internal battery pull down resistor.




Figure 34 Battery pin order

The battery temperature is estimated by measuring separate battery temperature NTC via the BTEMP line of EM ASIC (N2200). This resistor is located on the main PWB, at a place where the phone temperature is closest to the battery temperature.

Battery connector

The battery connector is a blade connector. It has three blades;

- BSI (Battery size indicator)
- GND (Ground)
- VBAT (Battery voltage)

The BSI line is used to recognize the battery capacity by a battery internal pull down resistor.



Figure 35 Blade battery connector

Charging

This phone is charged through the smaller Nokia standard interface (2.0 mm plug). The wider standard charger plug (3.5 mm) can be used together with a CA-44 charger adapter.



Figure 36 Small (right) and wide (left) charger plugs

The phone can also be charged via USB using CA-101.

Charging is controlled by EM ASIC (N2200), and external components are needed to protect the baseband module against EMC, reverse polarity and transient frequency deviation.

Charging a dead battery

Charging of a dead battery has to be carried out via an approved NOKIA charger. If the phone is charged via USB, CA-101 must be used.

Normal and extreme voltages

Energy management is mainly carried out in the EM ASIC (N2200). that contains a number of regulators. In addition there are also some external regulators.

In the table below normal and extreme voltages are shown when a BL-6Q battery is used.

Table 11 Nominal voltages

Voltage	Voltage [V]	Condition
General Conditions		
Nominal voltage	3.700	
Lower extreme voltage	3.145	
Higher extreme voltage	4.230	
(fast charging)		
HW Shutdown Voltages		
Vmstr+	2.1 ± 0.1	Off to on
Vmstr-	1.9 ± 0.1	On to off
SW Shutdown Voltages		
Sw shutdown	3.1	In call
Sw shutdown	3.2	In idle
Min Operating Voltage		
Vcoff+	2.9 ± 0.1	Off to on
Vcoff-	2.6 ± 0.1	On to off

Power key and system power-up

When the battery is placed in the phone, the power key circuits are energized. When the power key is pressed, the system boots up (if an adequate battery voltage is present).

Power down can be initiated by pressing the power key again and the system is powered down with the aid of SW. The power key is connected to EM ASIC (N2200) via the PWRONX signal.

Modes of operation

Mode	Description
NO_SUPPLY	(Dead) mode means that the main battery is not present or its voltage is too low (below EM ASIC master reset threshold) and that the back-up battery voltage is too low.
BACK_UP	The main battery is not present or its voltage is too low but back-up battery voltage is adequate and the 32 kHz oscillator is running (RTC is on).
PWR_OFF	In this mode (warm), the main battery is present and its voltage is over EM ASIC master reset threshold. All regulators are disabled, PurX is on low state, the RTC is on and the oscillator is on. PWR_OFF (cold) mode is almost the same as PWR_OFF (warm), but the RTC and the oscillator are off.
RESET	RESET mode is a synonym for start-up sequence. RESET mode uses 32kHz clock to count the RESET mode delay (typically 16ms).
SLEEP	SLEEP mode is entered only from PWR_ON mode with the aid of SW when the system's activity is low.
FLASHING	FLASHING mode is for SW downloading.

Clocking scheme

In BB5.44, two main clocks are provided to the system: 38.4MHz RF clock produced by VCTCX0 in the RF section and 32.768kHz sleep clock produced by EM ASIC N2200 with an external crystal.

32 k Sleep Clock is always powered on after startup. Sleep clock is used by RAPU for low-power operation.

SMPS Clk is 2.4MHz clock line from RAPU to EM ASIC N2200. In deep sleep mode, when VCTCX0 is off, this signal is set to '0'-state.

CLK600. The clock source is an internal RC oscillator in EM ASIC N2200 (during the power-up sequence) or RAPU SMPS Clk.

Bluetooth and WLAN have a separate 38.4MHz TCX0 clock oscillator.

Power distribution




Figure 37 Power distribution diagram

■ USB

USB interface

The phone has an interface for USB (Universal Serial Bus). USB is a differential serial bus that provides a wired connectivity between the phone and, for example, a PC or a headset.




Figure 40 USB interface

The phone supports USB 2.0 with High-Speed (480 Mbps).

Hot swap is supported, which means that USB devices may be plugged in and out at any time.

MicroUSB connector

This phone is provided with a specific connector for microUSB.




Figure 41 MicroUSB connector

■ User interface

Display interface

The following block diagram illustrates the display interface. Command signals and transmitted data to the display module comes directly from RAPU.

Display backlight is provided by an external LED driver.




Figure 42 Display interface

Keyboard interface

The following block diagram shows the keyboard interface. The keyboard interface contains an IO expander that is controlled by the I2C bus. The IO expander scans:

- The main keyboard
- The capture key
- The two volume keys

Decoupling components are implemented between the IO expander and the keys. When a key is pressed, an interrupt is sent to RAPU.

Side keys at the UI keymat are connected directly to the RAPU GENIOs.

The LEDs at the main keyboard are controlled by a LED driver. The driver is controlled by the I2C bus.




Figure 43 Keyboard interface

Ambient light sensor (ALS) interface

Ambient light sensor information is used to control keyboard and display brightness.

- Keyboard backlight is turned OFF, when it is not needed.
- Display brightness is dimmed, when environment lighting is dark.

The ambient light sensor is calibrated in production and can be re-tuned in service points, though not recommended unless calibration coefficient is lost for some reason




Figure 44 Ambient light sensor (ALS) interface


Accelerometer

The accelerometer measures the static acceleration of gravity in tilt-sensing applications, as well as dynamic acceleration resulting from motion or shock.

It has the following features:

- 2.4V to 3.6V supply voltage
- 1.8V compatible IOs
- low power consumption
- I2C output interface

The accelerometer (N6575) is connected to I2C. One GENIO is reserved for interrupt triggered by tap commands.



■ GPS interface

The phone includes a built in GPS receiver and could operate as a stand-alone positioning device. The antenna for GPS is located at the top of the A-cover, see section [GPS antenna \(page 5– 0 \)](#).

The GPS receiver is connected to RAPU ASIC.




Figure 45 GPS interface

■ Camera interface

In this phone the camera and the camera flash driver are connected directly to RAPU and controlled by the I2C bus, port 0. The camera is supplied by separate voltage regulators enabled by the camera software (GENIOs).

Control signals to and from the camera flash driver are connected directly to RAPU (GENIOs).




Figure 46 Camera interface

■ Audio interface

The following block diagram illustrates the audio interface of the phone:




Figure 47 Audio interface

The two digital microphones, Digi mic 1 and Digi mic 2, are connected directly to RAPU.

The earpiece is driven directly by a built-in amplifier included in EM ASIC.

The IHF speaker is driven directly by a built-in stereo amplifier included in EM ASIC.

The vibra is driven directly by a built-in amplifier included in EM ASIC.

■ Bluetooth interface

Bluetooth provides a fully digital link for communication between a master unit (the phone) and one or more slave units (e.g. a wireless headset). Data and control interface for a low power RF module is provided by the BTHFM module.

Bluetooth is physically integrated with FM radio in the BTHFM module ASIC, but from a functional point of view they have nothing in common




Figure 48 Bluetooth interface

The BTHFM module is powered by VBAT and the regulated voltage VIO. For audio applications the Bluetooth has a PCM data bus. In addition an UART (universal asynchronous receiver/transmitter) is used for data communication and controls.

Bluetooth shares the antenna with WLAN.


■ RF description

Receiver (RX)

An analogue signal is received by the phone's antenna. The signal is converted to a digital signal and is then transferred further to the baseband (e.g. to the earpiece).

The receiver functions are implemented in the RF ASIC.

Signals with different frequencies take different paths, therefore being handled by different components. The principle of GSM and WCDMA is the same.




Transmitter (TX)

The digital baseband signal (e.g. from the microphone) is converted to an analogue signal, which is then amplified and transmitted from the antenna. The frequency of this signal can be tuned to match the bandwidth of the system in use (e.g. GSM900).

The transmitter functions are implemented in the RF ASIC.

Even though the GSM and WCDMA signals are sent via different components, the principle of the transmission is the same.



Nokia Customer Care

Glossary

(This page left intentionally blank.)

A/D-converter	Analogue-to-digital converter
ACI	Accessory Control Interface
ADC	Analogue-to-digital converter
ADSP	Application DPS (expected to run high level tasks)
AGC	Automatic gain control (maintains volume)
ALS	Ambient light sensor
AMSL	After Market Service Leader
ARM	Advanced RISC Machines
ARPU	Average revenue per user (per month or per year)
ASIC	Application Specific Integrated Circuit
ASIP	Application Specific Interface Protector
B2B	Board to board, connector between PWB and UI board
BA	Board Assembly
BB	Baseband
BC02	Bluetooth module made by CSR
BIQUAD	Bi-quadratic (type of filter function)
BSI	Battery Size Indicator
BT	Bluetooth
CBus	MCU controlled serial bus connected to UPP_WD2, UEME and Zocus
CCP	Compact Camera Port
CDMA	Code division multiple access
CDSP	Cellular DSP (expected to run at low levels)
CLDC	Connected limited device configuration
CMOS	Complimentary metal-oxide semiconductor circuit (low power consumption)
COF	Chip on Foil
COG	Chip on Glass
CPU	Central Processing Unit
CSD	Circuit-switched data
CSR	Cambridge silicon radio
CSTN	Colour Super Twisted Nematic
CTSI	Clock Timing Sleep and interrupt block of Tiku
CW	Continuous wave
D/A-converter	Digital-to-analogue converter
DAC	Digital-to-analogue converter
DBI	Digital Battery Interface
DBus	DSP controlled serial bus connected between UPP_WD2 and Helgo

DCT-4	Digital Core Technology
DMA	Direct memory access
DP	Data Package
DPLL	Digital Phase Locked Loop
DSP	Digital Signal Processor
DTM	Dual Transfer Mode
DtoS	Differential to Single ended
EDGE	Enhanced data rates for global/GSM evolution
EGSM	Extended GSM
EM	Energy management
EMC	Electromagnetic compatibility
EMI	Electromagnetic interference
ESD	Electrostatic discharge
FCI	Functional cover interface
FPS	Flash Programming Tool
FR	Full rate
FSTN	Film compensated super twisted nematic
GMSK	Gaussian Minimum Shift Keying
GND	Ground, conductive mass
GPIO	General-purpose interface bus
GPRS	General Packet Radio Service
GSM	Group Special Mobile/Global System for Mobile communication
HSDPA	High-speed downlink packet access
HF	Hands free
HFCM	Handsfree Common
HS	Handset
HSCSD	High speed circuit switched data (data transmission connection faster than GSM)
HW	Hardware
I/O	Input/Output
IBAT	Battery current
IC	Integrated circuit
ICHAR	Charger current
IF	Interface
IHF	Integrated hands free
IMEI	International Mobile Equipment Identity
IR	Infrared

IrDA	Infrared Data Association
ISA	Intelligent software architecture
JPEG/JPG	Joint Photographic Experts Group
LCD	Liquid Crystal Display
LDO	Low Drop Out
LED	Light-emitting diode
LPRF	Low Power Radio Frequency
MCU	Micro Controller Unit (microprocessor)
MCU	Multiport control unit
MIC, mic	Microphone
MIDP	Mobile Information Device Profile
MIN	Mobile identification number
MIPS	Million instructions per second
MMC	Multimedia card
MMS	Multimedia messaging service
MTP	Multipoint-to-point connection
NFC	Near field communication
NTC	Negative temperature coefficient, temperature sensitive resistor used as a temperature sensor
OMA	Object management architecture
OMAP	Operations, maintenance, and administration part
Opamp	Operational Amplifier
PA	Power amplifier
PDA	Pocket Data Application
PDA	Personal digital assistant
PDRAM	Program/Data RAM (on chip in Tiku)
Phoenix	Software tool of DCT4.x and BB5
PIM	Personal Information Management
PLL	Phase locked loop
PM	(Phone) Permanent memory
PUP	General Purpose IO (PIO), USARTS and Pulse Width Modulators
PURX	Power-up reset
PWB	Printed Wiring Board
PWM	Pulse width modulation
RC-filter	Resistance-Capacitance filter
RF	Radio Frequency

RF PopPort™	Reduced function PopPort™ interface
RFBUS	Serial control Bus For RF
RSK	Right Soft Key
RS-MMC	Reduced size Multimedia Card
RSS	Web content Syndication Format
RSSI	Receiving signal strength indicator
RST	Reset Switch
RTC	Real Time Clock (provides date and time)
RX	Radio Receiver
SARAM	Single Access RAM
SAW filter	Surface Acoustic Wave filter
SDRAM	Synchronous Dynamic Random Access Memory
SID	Security ID
SIM	Subscriber Identity Module
SMPS	Switched Mode Power Supply
SNR	Signal-to-noise ratio
SPR	Standard Product requirements
SRAM	Static random access memory
STI	Serial Trace Interface
SW	Software
SWIM	Subscriber/Wallet Identification Module
TCP/IP	Transmission control protocol/Internet protocol
TCXO	Temperature controlled Oscillator
Tiku	Finnish for Chip, Successor of the UPP
TX	Radio Transmitter
UART	Universal asynchronous receiver/transmitter
UEME	Universal Energy Management chip (Enhanced version)
UEMEK	See UEME
UI	User Interface
UPnP	Universal Plug and Play
UPP	Universal Phone Processor
UPP_WD2	Communicator version of DCT4 system ASIC
USB	Universal Serial Bus
VBAT	Battery voltage
VCHAR	Charger voltage
VCO	Voltage controlled oscillator

VCTCXO	Voltage Controlled Temperature Compensated Crystal Oscillator
VCXO	Voltage Controlled Crystal Oscillator
VF	View Finder
Vp-p	Peak-to-peak voltage
VSIM	SIM voltage
WAP	Wireless application protocol
WCDMA	Wideband code division multiple access
WD	Watchdog
WLAN	Wireless local area network
XHTML	Extensible hypertext markup language
Zocus	Current sensor (used to monitor the current flow to and from the battery)

(This page left intentionally blank.)