


3155/3155i (RM-41), 3152 (RM-61) Schematics - Main PWB


Top Level

Version 1, edit 247




Baseband - Top Level

Version 5, edit 392




Version 12, edit 110





Audio

Version 1, edit 252




N7100 Rx Downconverter

Version 12, edit 96





Key UI

Version 13, edit 292




Memory

Version 0.5, edit 214




PA

Version 7.5, edit 113




RF-BB Interface


Version 0.5, edit 235



RF - Top
Version 0.5, edit 392




Version 0.0, edit 193




System Connector

Version 0.5, edit 284

.....




UHF Synthesizer
Version 12, edit 104




UEME

Version 1, edit 260




USE 4346047 IF TIKU2 USED ON SHEET 10

Version 0.3, edit 130




N7000 Tx Upconverter




Version 7.5, edit 117




Version 1.3, edit 205



Version 0.5, edit 158




Version 7, edit 141



3155i GPS BB


Version 7, edit 191




Make an ESD GND moat around the GPS module

3155 and 3152 (Non-GPS) Component Layouts and Values — Secondary Display


3155 and 3152 Component Layout - Top




3155 and 3152 Component Layout - Bottom



3155i Component Layout - Top



3155i Component Layout - Bottom



This page intentionally left blank.