

Service schematics

IMPORTANT

This document is intended for use by authorized Nokia service centers only. Please use the document together with other documents such as the Service Manual and Service Bulletins.

Version information

While every effort has been made to ensure that the document is accurate, some errors may exist. Please always check for the latest published version for this document.

If you find any errors in the document please send email to: service.manuals@nokia.com

1.0 First approved version.



Nokia C2-05


RM-724


Nokia C2-05.1


RM-725


Contents


Front page	1
X-GOLD, Power, HS USB, Camera, SIM	2
X-GOLD, Memory, MMC, Audio	3
X-GOLD, Display, Keymat	4
X-GOLD, RF part, RF power, BTH	5
UI flex board	6
Test points top	7
Component finder bottom	8
Component finder UI flex board	9











C	
C1000	B3
C1001	B3
C1002	C2
C1003	B3
C1004	A3
C1005	A3
L	
L1000	B2
L1001	B2
L1002	A3
R	
R1002	B2
R1004	A3
R1005	A3
S	
S1000	A2
S1001	B2
S1002	C2
S1003	B1
S1004	B1
S1005	C1
S1006	C2
S1007	A2
S1008	B1
V	
V1000	B2
X	
X1000	D2
X1000	C3

