

Service Guide

Product : GSM

Model : SGH-E840 Sep. 20, 2007

SUBJECT: Firmware Updating of Touch Key

1. Purpose:

- In order to inform repair engineers of technical information.

2. Symptom

- Improvement of Touch Key sensitivity

3. Change:

- Touch Version: 1.0 -> 2.0 (to improve the level of recognition)

3. The way to check the existing Touch Version:

- 1. Input Key String *#0206*8376263#
- 2. Check whether the Touch Version is 1.0 or 2.0. (Ver 2.0 is the most optimized version currently)



4. Repair Instruction :

In case of Touch Version 1.0,

Engineer might make the improvement by touch key firmware update.

But, mostly the touch key sensetivity depends on the feeling & condition of individual user.

- 1. Download the latest SW Version released after 28.May (Touch Version 2.0 applied to SW from after GE3)
- 2. Input Key String *#9998*86824# to update of Touch Version 2.0 (It needs about 10~20sec to complete downloading)
- 3. The message "Touch Code Download Completed!" will appear after completing update
- 4. Check the Touch Version be changed 1.0 into 2.0 after Inputting Key String *#0206*8376263#

