

Service Schematics



RM-638



IMPORTANT

This document is intended for use by authorized Nokia service centers only. Please use the document together with other documents such as the Service Manual and Service Bulletins.

Version information

While every effort has been made to ensure that the document is accurate, some errors may exist. Please always check for the latest published version for this document.

If you find any errors in the document please send email to:
TrainingAndVendorDevelopment@nokia.com

Version history


1.0 First Approved version


Table of Contents


Front page	1
RAPS, HS USB, Sensors, Camera, Memory	2
GAZ00, Audio, MMC, SIM, Battery	3
User Interface, Keyboard, Keyboard Backlighting	4
BTHFM	5
RF part	6
Component Finder Top	7
Component Finder Bottom	8


Copyright © Nokia
This material,including documentation and any related computer programs is protected by copyright, controlled by Nokia. All rights are reserved. Copy- ing, including reproducing, modifying, storing, adapting or translating any or all of this material requires the prior written consent of Nokia. This material also contains company confidential information, which may not be disclosed to others without the prior written consent of Nokia.











E		V	
E1000	E10	V2500	F5
E1001	K10	V2502	F7
E1003	E2	V2504	B7
E1004	K2	V2506	B4
N		V2512	I4
N2460	U4	V2513	I7
S		X	
S2403	U6	X2060	U7

